"DOUBLE PLAY" 4-1-77
UPRIGHT MODEL
MIDWAY MFG. CO.
10750 GRAND AVE.
FRANKLIN PARK, ILL.
60131
WIRE COLOR CODE
B=BLACK O=ORANGE
BLU=BLUE R=RED
BR=BROWN W=WHITE
G=GREEN Y=YELLOW
EXAMPLE:
G-R INDICATES GREEN WIRE WITH RED TRACER
ABBREVIATIONS USED
J=JUMPER SW=SWITCH
RE=RELAY POS=POSITION
SU=STEP UP UNIT
OSC=OSCILLATING
SWITCH SYMBOLS
"NORMALLY OPEN" CLOSED WHEN ENERGIZED.
"NORMALLY CLOSED" OPEN WHEN ENERGIZED.
MAKE & BREAK
MOTOR CAM SWITCH
.1 MFD. CAPACITOR
1 AMP SLO-BLO FUSE
DISPLAY LITES TABLE MODEL ONLY
3 AMP FUSE
P.C.0080-00904D POWER SUPPLY
220V.
115V.
105V.
14V.
16.5V.
9V.
C.TAP
ON-OFF SW.
20 WATT BALLAST CE-120
FAN MOTOR 612-0460 TABLE MODEL ONLY
F20T12BL BLACKLITE
MT-50A XFORMER 60CYCLE
MT-51A XFORMER 50CYCLE
MONITOR JACK
TO COIN DOOR AND CONTROL PANEL
-5V.
+12V.
-SENSE
COM
+5V.
V. AUDIO
RESET
AUDIO RETURN
TILT SW.
1N4004
COIN METER
SPEAKER
(2) COIN SWS.
18 PIN CONNECTOR
11 PIN CONNECTOR
MOTHER BOARD P.C.0080-00900D
GAME LOGIC BOARD P.C.0619-00902
72 PIN CONNECTOR
MXO MX1 MX2 MX3 MX4 MX5 MX6 MX7 A8 A9 A10 SAMPLE D0 D1 D2 D3 D4 D5 D6 D7 HOLD RESET 60HZ ØIT
INDICATES PIN NUMBER IDENTIFIED ON P.C. BOARD NOT JACK POSITION
INDICATES JACK POSITION NUMBER
15 PIN CONNECTOR
BARE
VISITORS PLAYER BAT
HOME PLAYER BAT
FIELDER MOVES LEFT
FIELDER MOVES RIGHT
PITCH LEFT
PITCH RIGHT
PITCH SLOW
PITCH FAST
SELECT ONE PLAYER
SELECT TWO PLAYER